

D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

Triumph Rocket III Touring Slip-Ons 541-12

1. Remove seat and saddlebag.
2. Disconnect battery. Negative terminal first.
3. Remove stock air cleaner
4. Install new K&N air filter per supplied instructions.
5. Reinstall air box cover.
6. Remove the stock mufflers. Retain the heatshields as they will be reused.
7. Install new D&D mufflers. Make sure the supplied clamps are even with the end of the muffler.
8. Tighten rear muffler mounts.
9. Tighten clamps to 150 in.lbs.
10. Replace stock heatshields.
11. Clean mufflers with glass cleaner to remove and oil and fingerprints.
12. Reinstall saddlebags.
13. Reconnect battery.
14. Install Triumph download #20235
15. Start motorcycle and check for leaks.