

D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

2008 Yamaha R6

545-11/12 A-B

1. Disconnect negative battery terminal.
2. Remove muffler heat shield
3. Disconnect exhaust servo cables from the muffler.
4. Remove factory muffler. Retain factory mount bolt as this will be used later.
5. Remove cables from servo (Servo is located in front of the rear shock. Cables can be accessed from the right side of the bike.). Leave servo attached and connected.
6. Remove cables from motorcycle.
7. Inspect new muffler. No warranty on cosmetics once muffler has been installed.
8. Install D&D muffler using supplied muffler clamp and the factory mount bolt and supplied flange nut.
9. Snug mount bolt.
10. Tighten muffler clamp to 150 in.lbs.
11. Tighten mount bolt to factory torque spec.
12. Clean muffler with glass cleaner to remove any oil or finger prints.
13. Reconnect battery, start and check for leaks.