

D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

2009 HD Touring “Boss” Ghost Pipe 549G

To be used with the “Boss” 2-1 #549-31/32

1. Remove left saddlebag.
2. Remove stock crossover mount, bolted to the lower rear oil pan. Retain these bolts as they will be used later.
3. Open box and inspect pipe. No warranty for cosmetics after installation.
4. Loosely mount rear of ghost pipe to saddlebag support using supplied hardware and spacers.
5. Attach ghost pipe front mount to oil pan using existing hardware. Be sure to apply blue loctite to threads.
6. Check alignment.
7. Torque bolts to oil pan using factory specifications.
8. Tighten rear of muffler to the saddlebag support.
9. Clean system with glass cleaner to remove any oil and fingerprints.
10. Install saddlebag.