

# D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

## **Kawasaki Vulcan 1700 Nomad / Voyager 554-12**

1. Remove seat and saddlebags.
2. Disconnect battery. Negative terminal first.
3. Remove the stock mufflers. Retain the heatshields as they will be reused.
4. Open package and inspect all parts. No warranty on cosmetics after system has been installed.
5. Install new D&D mufflers.
6. Tighten rear muffler mounts.
7. Tighten clamps.
10. Replace stock heatshields.
11. Clean mufflers with glass cleaner to remove and oil and fingerprints.
12. Reinstall saddlebags.
13. Reconnect battery.
15. Start motorcycle and check for leaks.