

D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

2009-2010 Honda Fury Slip-On's 558-12

1. Disconnect battery. Negative terminal first.
2. Remove the stock mufflers. Retain mounting hardware as it will be reused.
3. Open package and inspect the system. No warranty for cosmetic blemishes after the system is installed.
4. Install new D&D mufflers using the stock mounting hardware. Make sure the supplied clamps are even with the end of the muffler.
5. Tighten rear muffler mounts.
6. Tighten clamps to 150 in.lbs.
7. Clean mufflers with glass cleaner to remove all oil and fingerprints.
8. Reconnect battery.
9. Start motorcycle and check for leaks.