

D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

2008-2010 FXDF, 2010 FXDWG Slip-ons 559-12

1. Remove main fuse.
2. Remove the stock mufflers.
3. Open package and inspect the system. No warranty for cosmetic blemishes after the system is installed.
4. Install new D&D mufflers. Make sure the supplied clamps are even with the end of the muffler.
5. Install bracket on lower pipe using the supplied bolt and washers along with the stock bolt removed from the rear of the stock mufflers. Align with mount point.
6. Using the stock long bolt and supplied flange nut attach both mufflers to the factory bracket.
7. Tighten muffler mounts.
8. Tighten clamps to 150 in.lbs.
8. Clean mufflers with glass cleaner to remove all oil and fingerprints.
9. Reinstall main fuse.
10. Start motorcycle and check for leaks.

Tuner required when using this system with a high flow air cleaner.