

D&D Performance Enterprises

2923 Edith lane

Ft.Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

2009 - 2010 HD Touring “Boss”Zilla 2-1

566-31/32

1. Remove saddlebags.
2. Remove main power fuse from left side.
3. Remove right side floorboard.
4. Disconnect O2 sensor plugs.
5. Remove stock exhaust system (Retain stock transmission mount and hardware).
6. Remove factory O2 sensors from stock header.
7. Open box and inspect all system components (No warranty for cosmetics after pipe has been installed).
8. Install new exhaust gaskets.
9. Apply a small amount of Anti-Seize to the threads of the factory O2 sensors (Be careful not to get any on the end of the sensor) and install sensors in the new header. Remove the unused O2 sensor plugs in the pipe, apply red loctite and tighten.

10. Install header on motorcycle. The mount tab on the pipe goes on top of the transmission mount.
11. Loosely install factory mounting hardware.
12. Install muffler with supplied hardware.
13. Tighten hardware (To factory specifications) starting at the heads and working to the rear of the bike (Make sure the mount at the transmission does not bind).
Check alignment as you go.
14. Reconnect O2 sensors.
15. Install right side floorboard.
16. Clean entire system with glass cleaner to remove any oil and fingerprints.
17. Install main fuse.
18. Install right side cover and saddlebags.
19. Install Hi-Flow air cleaner according to manufactures instructions
20. Start motorcycle and check for leaks.

This system is designed to be used with a fuel management system matched to the engine modifications.